

Wheel Horse®


LAWN AND GARDEN TRACTORS

TRAILBLAZER "7" SNOW THROW

MODEL
4-2651



OWNERS MANUAL



"Quality is Standard Equipment in Every Wheelhorse Product"




FIGURE 1

ASSEMBLY:

Remove Snow Thrower and all other parts from carton.

1. Assemble upper handles, MW-10284 and panel, 6599 to lower handle with three hex bolts and one $\frac{5}{16}$ eyebolt which goes in the upper hole on the right hand side. The eye of the eyebolt must be on the inside of handles. Secure with four $\frac{5}{16}$ elastic stop nuts. See Figure 1 and Exploded View drawing.

2. Assemble control handle, 6545, to the upper handle using two bushing, one $\frac{5}{16} \times 1\frac{1}{2}$ hex bolt (right side), one $\frac{5}{16} \times 1\frac{3}{4}$ hex bolt (left side), and two $\frac{5}{16}$ elastic stop nuts. See the exploded view drawing and Figure 1.

3. Screw the trunnion stud 5791 onto the clutch rod 6544 and install trunnion stud and rod assembly between control handle and the clutch arm assembly 6983 and secure trunnion stud to the clutch arm assembly with hairpin cotter 933504-4.

Place upper end of clutch rod 6544 through hole in control handle. To properly adjust the clutch rod start the engine (see starting procedure) and move shift rod to low, squeeze on the right side of the control handle. The clutch should reach a firm engagement before the clutch rod handle touches the handle grip. If it is too tight or too loose, remove rod from hole and turn in trunnion stud until correct adjustment is achieved. Next insert threaded end of reverse stop rod 100232 through eyebolt, and attach other end over the clutch rod end as shown above (Figure 1). Secure upper end with cotterpin 932008-4. Screw $\frac{5}{16}$ nut on threaded end of rod. This nut is for adjustment in reverse, so that an excess amount of pressure cannot be applied on the reverse belt. With control handle 6545 pulled in reverse position, adjust $\frac{5}{16}$ nut up until it makes contact with eyebolt. (**Note:** When pulling back on clutch bar for reverse, the nut of the reverse stop rod should always make contact with the eyebolt. Adjust nut so that there is just enough rearward movement of the clutch bar for reverse traction and no more.)

OIL AND GASOLINE:

DO NOT MIX OIL WITH GASOLINE.


Fill gas tank with clean **regular** gasoline.

Fill engine crankcase with SAE 5W 20 which is recommended, however for temperatures above 0°F. SAE 10W 30 is satisfactory. Fill to (Full) mark on dip stick. **Caution: Do Not Overfill.**

ROTOR GEAR BOX:

The proper amount of oil was installed at the factory but should be checked before using.

Remove check plug on gear box, if oil is not to the check plug level, remove fill plug and add SAE #90 Hypoid Gear Lube until oil runs out of the check plug. The oil level should be checked every 8 to 10 hours of operation.



TRANSMISSION:

The transmission has been lubricated at the factory and requires only seasonal (see maintenance) attention. The grease fitting on the right hand wheel hub should be lubricated before using and then after every eight to ten hours of operation. Use regular pressure gun lubricant.

A light machine oil should be used on all moving parts to prevent rust and to keep linkages working freely.

STARTING:

For safe starting, it is necessary to make sure that the rotor clutch is in the disengaged position and the shift lever is in the neutral position.

PRE START:

1. Check engine oil level.
2. Refuel engine with fresh winter blend regular gasoline from sealed container.
3. Place manual choke in full choke position.
4. Place throttle in run position.
5. Open fuel shut off valve on gas tank.

STARTING PROCEDURE:

1. Temperatures 10° F. and below use "Primer."
 - A. To Prime Engine:
 1. With primer button held in, pull engine slowly over compression once.
 2. Release primer button.
 2. To start, pull engine on compression, then pull starter handle quickly.
 3. When engine starts, advance choke immediately to $\frac{3}{4}$ choke position (first notch).
 4. As the engine warms up advance to $\frac{1}{2}$ choke and no choke position.
If engine falters return to $\frac{1}{2}$ choke and repeat.
 5. Warm Up Period: Let engine run $\frac{1}{2}$ throttle $\frac{1}{2}$ minute, then slowly engage rotor clutch and run one minute before blowing snow.
 6. For final shut down, stop engine by closing fuel shut off valve on gas tank.
Do not refuel engine at this time.




FIGURE II

TO STOP ENGINE:

Place shift lever in the neutral position and slide throttle lever into the stop position, as far as possible. (See above photo.)

To avoid accidents, shut off engine before adding gas, oil, before making adjustments, or inspections of any kind.

TO THROW SNOW:

Place throttle lever in **wide open**, run position, engage rotor clutch slowly. Place shift control in desired range (low or hi), and squeeze handle on right hand

handle bar to go forward. To go in reverse pull back on the cross bar above the handles. The machine will back up only when the cross bar is pulled back. When the control is released the machine will stop regardless of direction of travel.

To change direction or distance of throw, turn chute crank accordingly. Move capper up or down, by loosening wing nuts, tighten nuts securely after adjustment.

CAUTION: Always STOP ENGINE and disengage rotor clutch before attempting to remove obstructions from the chute or rotor.


If an object should get jammed in the rotor, proceed as follows:

1. Shut off engine, and disconnect spark plug wire.
2. Using long screw driver reach down through chute opening and rotate impeller blades clockwise. This will release object.
3. Remove object, check for visible damage, re-start engine and engage rotor clutch slowly and observe for any operational damage.
4. If chute should become plugged with snow, DO NOT stick your hand in chute and attempt to clean it out. Disengage rotor clutch and **shut off engine**. The chute should be cleaned out with something other than your hand.

The rotor shear pins are designed to protect parts from becoming damaged when the rotors become lodged with an object too large to be handled by the Snow Thrower. It is important they be replaced with a genuine Wheel Horse Shear Pin. No. 7491.

TO ADJUST SKIDS — First Shut Off Engine

FOR USE ON CONCRETE — adjust skids $\frac{1}{2}$ inch lower than scraper blade. FOR USE ON GRAVEL — adjust skids one inch lower than scraper blade. NOTE: These adjustments move entire unit up or down.



TO ADJUST SCRAPER — First Shut Off Engine

The blade is adjusted by 5 bolts which hold blade to chassis. Blade is located behind rotor. FOR USE ON CONCRETE — adjust blade $\frac{1}{2}$ inch lower than rotor. FOR USE ON GRAVEL — adjust blade to level of rotor.

If the snow discharge chute binds or will not stay in place it can be adjusted as follows:

CHUTE TURNING TENSION ADJUSTMENT:

Loosen the nut that secures the chute rod hanger bracket (Item No. 77, Part No. 7237). Slide the bracket down to relieve bind or up to correct looseness, then tighten the nut.

DIFFERENTIAL LOCK:

A differential lock has been provided on this machine to produce maximum traction under adverse conditions.

If one wheel loses traction and spins, both wheels can be made to drive by rotating the pin in the differential lock on the right hand wheel hub and letting the cross pin drop into the deep notch. This locks the differential forcing both wheels to drive at all times. For easiest handling under normal conditions the pin should be pulled out and the cross pin turned to engage the shallow notch. This permits the operator to turn the machine with far less effort because skidding of the wheels is eliminated.




FIGURE III

SEPARATION OF SNOW HANDLER FROM PROPULSION UNIT:

To separate the snow handler from the propulsion unit the following procedure should be followed:

1. Remove plastic belt cover 6539 by removing three (3) screws holding it.

2. Slip impeller drive belt 6506 off of engine pulley.

3. Rotate chute to extreme left hand position so that sprocket will disengage chute through slot provided in flange.

4. To unlock cam levers, rap cam lever arm, toward rotor and upwards, with short light raps of a hammer. Swing lock arms away from channels. Stand at operator's position and pull on handles to separate the propulsion unit from the rotor unit. To recouple reverse the above procedure. The cam locks can be adjusted by turning the cam lock trunnion in or out as required. **The locks should be adjusted to where it takes light raps of a hammer to pull them down.** The cams must be fully down and tight in order to obtain a positive lock.

BELT REMOVAL:

After separation of snow handler from propulsion unit, belt removal can be easily attained.




FIGURE IV

To change impeller drive belt 6506, remove hairpin 933505-4, slide one end of belt guide 6979 off pin and let it swing down. Now the belt can easily be removed.




FIGURE V

To change drive belts, remove belt guide 6994 below transmission pulley, then remove hairpin 933504-4 next to small idler pulley and slip spacer off of pin. Now the belts can be slipped off the pulleys.

MAINTENANCE:

Drain and refill crankcase after the **first** (2) hours of operation. Then drain and refill after each 25 hours of operation. — See engine manual.

Check oil in crankcase each time unit is used.

Check rotor gear case every 10 hours of operation.

Grease R.H. wheel hub (zerk provided) each 10 hours of operation.

Before the snow season check unit, tighten any loose bolts, lubricate transmission at the grease fittings with regular gun grease.

STORING:

Drain gas from tank. If the Snow Throw is to be stored for long periods. Remove engine spark plug, pour in about two tablespoons of motor oil, replace spark plug and crank engine a few turns.

To protect rotor from rust when storing coat it with a light coating of grease or oil.

Approximate shipping weight 260 lbs.


ACCESSORIES:

ELECTRIC START:

Electric starting is available as an accessory. Order Wheel Horse 8-0111.

TIRE CHAINS: 8-2111

Purchase from any Wheel Horse dealer.




SNOW HANDLING UNIT

SNOW THROW PARTS LIST

Parts available only through Authorized Dealers
When ordering parts always list Part No. and name of part.
(Specifications subject to change without notice.)

Item No.	Part No.	Description	No. Req'd.	Item No.	Part No.	Description	No. Req'd.
1	6976	Assembly — Rotor Housing	1	66	1432	Screw — Rd. Hd. $\frac{5}{16}$ -24 x $\frac{1}{2}$	2
2	6979	Guide — Belt	1	67	920082-4	Lockwasher $\frac{5}{16}$ Dia.	2
3	933505-4	Hairpin	1	68	6539	Cover — Belt	1
4	2138	Spacer	1	69	911685-4	Screw — Hex Hd. Slotted #14-10 x $\frac{7}{8}$	3
5	6980	Rod — Clamp	2	70	6994	Guide Belt	1
6	6981	Cam — Clamp	2	71	960163-4	Screw — Hex Hd. Whiz-Loc $\frac{1}{4}$ -28 x $\frac{1}{2}$	2
7	5791	Stud — Trunnion	3	72	MW-10294	Handle — Lower L.H.	1
8	932008-4	Cotter Pin $\frac{3}{32}$ x $\frac{3}{4}$	4	73	MW-10295	Handle — Lower R.H.	1
9	7489	Assembly Rotor L.H.	1	74	MW-10284	Handle — Upper	1
10	7488	Assembly Rotor R.H.	1	75	908021-4	Bolt — Hex $\frac{3}{16}$ -18 x $1\frac{1}{2}$	5
11	7491	Bolt — Shear $\frac{3}{16}$ -18	2	76	6542	Grip — Handle	2
12	915112-6	Nut — $\frac{5}{16}$ -18 Nylok	17	77	7237	Hanger	1
13	MW-10293	Assembly Impeller	1	78	5979	Bushing	1
14	933217	Roll Pin $\frac{1}{4}$ x $1\frac{1}{2}$	2	79	MW-10751	Bolt — Carriage $\frac{5}{16}$ -18 x $1\frac{3}{8}$	1
15	5269	Bearing — Flange Mount	1	80	920038-4	Washer $\frac{5}{16}$ US	1
16	909862-5	Set Screw $\frac{3}{16}$ -18 x $\frac{5}{16}$ Nylok	5	81	6544	Rod — Clutch	1
17	7985	Bearing — Flange Mount	2	82	6545	Handle — Control	1
18	943308-4	Nipple $\frac{1}{4}$ Pipe x $1\frac{1}{4}$	1	83	6990	Bushing	2
19	920124-4	Lockwasher $\frac{3}{8}$ Ext. Tooth	2	84	6546	Rod — Chute Control	1
20	MW-10512	Assembly — Scraper Blade	1	85	MW-8935	Sprocket — 9 Tooth	1
21	960010-4	Nut Whizlock $\frac{5}{16}$ -18	5	86	933173	Roll Pin $\frac{3}{32}$ x $1\frac{1}{4}$	1
22	MW-10507	Skid	2	87	6547	Spring	1
23	6352	Bolt — Lug $\frac{3}{8}$ -16 x $\frac{5}{8}$	2	88	6991	Collar — Hex	1
24	920009-4	Washer $\frac{3}{8}$ SAE	16	89	6383	Assembly — Wheel & Tire	2
25	MW-10340	Assembly Chute	1	90	5837	Wheel	2
26	MW-10276	Deflector	1	91	MW-10493	Tire	2
27	900062-4	Bolt — Carriage $\frac{3}{8}$ -16 x $\frac{3}{4}$	4	92	MW-10494	Tube	2
28	920011-4	Washer $\frac{1}{2}$ Dia. SAE	4	93	1004	Bolt — Lug $\frac{7}{16}$ -20	6
29	915113-6	Nut — $\frac{3}{8}$ -16 Nylok	11	94	MW-10739	Cover — Starter Opening	1
30	6973	Assembly — Wing Nut	2	95	MW-4194	Screw — Hex Slotted #10-24 x $\frac{3}{8}$	1
31	MW-10283	Assembly — Retainer	2	96	6599	Assembly Panel	1
32	908001-4	Bolt — Hex $\frac{1}{4}$ -20 x $\frac{1}{2}$	5	97	7413	Ball — Spherical	1
33	920007-4	Washer $\frac{1}{4}$ SAE	8	98	7414	Socket — Crank Bushing	1
34	MW-10376	Pulley — 8" Dia.	1	99	915112-6	Nut — $\frac{5}{16}$ -18 Nylok	1
35	937159	Key — Hi-Pro $\frac{3}{16}$ x $\frac{3}{4}$	1	100	8004	Engine 6 H.P.	1
36	6502	Assembly Lever	1	101	960012-4	Nut — Whizlock $\frac{3}{8}$ -16	4
37	MW-8821	Pulley — Idler	1	102	6536	Pulley — Crankshaft	1
38	908036-4	Bolt — Hex $\frac{3}{8}$ -16 x $1\frac{1}{2}$	1	103	MW-10304	Key — $\frac{1}{4}$ Square	1
39	6949	Spring	1	104	6535	Pulley — Cam Shaft	1
40	6505	Ring — Truarc	1	105	909850-5	Set Screw — Nylok	1
41	6290	Knob	1	106	7029	Assembly Throttle Control	1
42	6506	Belt 32" 4L	1	107	911263-4	Screw — Hex Sems #10-32 x $\frac{3}{8}$	1
43	932024-4	Cotter Pin	1	108	7030	Wire — Throttle Lever	1
44	6999	Assembly Housing	1	109	MW-10556	Eyebolt	1
45	6525	Housing — Diff. Lock	1	110	100232	Rod — Reverse Stop	1
46	6526	Pin — Diff. Lock	1	111	915662-4	Nut — $\frac{5}{16}$ -18 Elastic Stop	1
47	6293	Spring	1	112	6552	Belt — 30"	1
48	933270	Roll Pin	1	113	6551	Belt — 30.5"	1
49	933269	Roll Pin	1	114	7681	Decal — Safety	1
50	6527	Rod — Shift	1	115	8034	Decal — "7"	1
51	6528	Grip — Shift Rod	2	116	6819	Decal — Throttel Control	1
52	932016-4	Cotter Pin	4	117	MW-10545	Decal — Rotor Clutch	1
53	5842	Bracket	1	118	MW-8378	Decal — Caution Snow Chute	1
54	915111-6	Nut — Hex $\frac{1}{4}$ -20 Nylok	8	119	8063	Decal — Trailblazer	1
55	6983	Assembly — Clutch Arm	1	120	909540-4	Set Screw Sq. Hd. $\frac{5}{16}$ -18 x $\frac{1}{2}$	2
56	6775	Pulley — Forward-Rev. Idler	1	121	6519	Speed Nut #14-10	3
57	6593	Bearing — Ball $\frac{7}{16}$ I.D.	2	122	7628	Muffler	1
58	920201-4	Washer	2	123	908015-4	Bolt — Hex $\frac{5}{16}$ -18 x $\frac{1}{2}$	1
59	936115	Snap Ring $\frac{7}{16}$ Ext.	1	124	908000-4	Bolt — Hex $\frac{1}{4}$ -20 x $\frac{3}{8}$	1
60	6532	Bracket	2	125	908022-4	Bolt — Hex $\frac{5}{16}$ -18 x $1\frac{3}{4}$	1
61	6533	Spring	1	126	920008-4	Washer — $\frac{5}{16}$ SAE	1
62	936020	Snap Ring — Truarc	2	127	943317-4	Nipple $\frac{1}{4}$ Pipe x 4	1
63	4395	Spacer	1	128	943002-4	Elbow $\frac{1}{4}$ Pipe x 90°	1
64	933504-4	Hairpin	2	129	4217	Cap $\frac{1}{4}$ " Pipe	1
65	6987	Assembly — Cover & Guide	1				




PARTS LIST 7487 GEAR BOX – ROTOR DRIVE

(Order Part No. 7487 for Complete Gear Box)

When ordering parts always list Part No. and name of part.

Item No.	Part No.	Description	No. Req'd.	Item No.	Part No.	Description	No. Req'd.
1	MW-8869	Housing — Rotor Drive	1	13	937168	Key — Hi-Pro $\frac{1}{4}$ x 1	1
2	MW-5332	Bushing — Sleeve	2	14	7490	Shaft Rotor	1
3	5596	Bearing — Ball	1	15	7037	Cup — Timken	1
4	7038	Spacer — Worm	2	16	7036	Cone — Timken	1
5	MW-8938	Worm	1	17	MW-8870	Cover	1
6	937159	Key — Hi-Pro $\frac{3}{16}$ x $\frac{3}{4}$	1	18	5326	Gasket	1
7	936125	Ring — Retaining — $\frac{3}{4}$ Shaft	1	19	908002-4	Bolt — Hex $\frac{1}{4}$ -20 x $\frac{5}{8}$	4
8	936028	Ring — Retaining Int.	1	20	MW-10390	Seal — Oil 1.00 Shaft	2
9	7034	Shaft — Impeller	1	21	943418	Plug — Pipe	1
10	7039	Washer	1	22	MW-10440	Plug — Vent	1
11	MW-10327	Washer — Thrust	2	23	MW-10459	Seal — Oil $\frac{7}{8}$ Shaft	1
12	MW-8941	Gear — Worm	1	24	920081-4	Lockwasher $\frac{1}{4}$ Plain	4



PARTS LIST 5077 — TRANSMISSION

(Order Part No. 5077 for Complete Transmission)

When ordering parts always list Part No. and name of part.

(Specifications subject to change without notice.)

Item No.	Part No.	Description	No. Req'd.	Item No.	Part No.	Description	No. Req'd.
1	6671	Pulley	1	22	937017	Key — #11 Woodruff	1
2	920038-4	Washer	1	23	5751	Shaft — Sliding Gear	1
3	908016-6	Bolt $\frac{3}{16}$ -18 x $\frac{5}{8}$ Nylok	1	24	5755	Gear — Low	1
4	6520	Assembly Axle	1	25	5758	Gear — Sliding	1
5	5770	Assembly Flanged Ball Bearing	1	26	6678	Shaft — Hi-Low	1
6	1291	Fitting — Grease	1	27	6679	Pinion — Low	1
7	6522	Assembly Hub & Flange	1	28	6680	Gear — Combination	1
8	1504	Bushing	2	29	5752	Gear — High	1
9	1030	Fitting — Grease	1	30	6681	Shaft — Input	1
10	908031-4	Bolt — Hex $\frac{3}{8}$ -16 x $\frac{5}{8}$	2	31	6682	Gear — Pinion — Input	1
11	915113-6	Nut — $\frac{3}{8}$ -16 Nylok	2	32	936121	Snap Ring $\frac{5}{8}$ Ext.	1
12	5738	Case — R.H.	1	33	6192	Bearing Ball $\frac{5}{8}$ I.D.	2
13	7060	Bearing — Ball $\frac{5}{8}$ I.D.	4	34	6553	Assembly Shift Fork	1
14	1291	Fitting — Grease	2	35	933190	Roll Pin $\frac{3}{8}$ x $1\frac{1}{4}$	1
15	5746	Gear	1	36	6188	Spring	1
16	6639	Bearing — Ball $1\frac{1}{4}$ I.D.	1	37	3517	Ball	1
17	5747	Gear — Axle L.H.	1	38	5739	Case — L.H.	1
18	5745	Gear — Final Drive	1	39	5741	Bearing — Ball $1\frac{1}{4}$ I.D.	1
19	5748	Gear — Diff. Pinion	2	40	908018-4	Bolt — Hex $\frac{5}{16}$ -18 x $\frac{7}{8}$	6
20	5749	Washer — Thrust	2	41	915972-4	Nut — $\frac{3}{16}$ -18 Keps	8
21	5750	Pin — Diff.	2	42	908025-4	Bolt — Hex $\frac{5}{16}$ -18 x $2\frac{1}{2}$	2

SAFETY TIPS

1. Know the controls and how to stop quickly — READ THE OWNERS MANUAL.
2. Do not allow children to operate machine; nor adults to operate it without proper instruction.
3. Clear work area of objects which might be picked up and thrown.
4. Disengage all clutches and shift into neutral before starting motor. Keep hands, feet and clothing away from power-driven parts.
5. Keep children and pets a safe distance away.
6. Never direct discharge of any material toward bystanders nor allow anyone near machine while in operation.
7. Take precautions when leaving machine unattended (to avoid starting, rolling away).
8. Stay alert for holes and other hidden hazards.
9. Know what is behind you before backing up.
10. Beware of steep slopes; reduce speed on all side slopes and sharp turns to prevent tipping or losing control.
11. Don't stop or start suddenly when going uphill or downhill.
12. Watch out for traffic when near roadways.
13. Handle gasoline with care — it is highly flammable.
 - a. Use approved gasoline container.
 - b. Never add gasoline to a running motor — fill tank out of doors and wipe up spilled gasoline.
 - c. Replace gasoline cap securely.
 - d. Open doors if motor is run in garage — exhaust gases are dangerous.
14. Keep machine in good operating condition and keep safety devices in place.
15. Stop motor before making repairs or adjustments.

