

February, 1967

RECOMMENDED OIL AND FILTER CHANGE PERIOD

HYDRO-GEAR TRANSMISSIONS

The following applies to all hydro-gear transmissions and supercedes all previous recommendations on this subject.

FILTER CHANGE PERIOD

The oil filter should be replaced after the first ten (10) hours of operation, and thereafter once a year or after every one hundred (100) hours whichever occurs first. USE FILTER PART #5990.

OIL CHANGE PERIOD

The oil should be changed once a year or after every one hundred (100) hours of operation, whichever occurs first. USE ONLY TYPE "A" AUTOMATIC TRANSMISSION FLUID.

Atwood S. Kidder

Customer Relations Manager

atwood S. Kidder